Complete loom wiring.

The ground lead connects the headshell and arm body. The carbon fibre tube is electrically bonded to the metal at each end. The arm base and the screen of the interconnect are grounded. This forms a complete screen from headshell to RCAs and is not connected to the signal path at all.

With a phono stage that accepts balanced signal into RCAs this will give a true balanced connection.



